

# Manchester II Aluminum Arbor by Specrail



## Easy as 1-2-3!

If you are familiar with using a cordless drill, measuring tape, a level and a shovel - you can install the Manchester II in 30 minutes!

Preparation: Identify 2 pcs. Part A (lower side panel), 2 pcs. Part B (upper side panel with plastic connector cover), 6 pcs. spindles, 2 pcs. arch top frame and 1 bag of screws.

### Step 1. Assembly of the Body

Place Part B into Part A and secure with screws. Slide the connector cover on Part B over the screw attachment. Attach the 6 Spindles to the arch top frames with furnished screws.

### Step 2. Raising the Arch

Attach the arch top unit to the two assembled side panels by snapping the 2" cap over the 2" side panel posts. Secure with furnished screws. Unit is now ready to stand up and locate the post setting.

### Step 3. Securing your Arbor

Mark location of the four posts and dig a 16"-18" deep hole for each post. Set unit in the holes and insure that posts are level. Secure unit in place with concrete or compact earth around posts.

- Fast & Easy Installation
- Quality Aluminum Construction
- Factory powder coated finish
- Limited-Lifetime Warranty



**SPECRAIL**<sup>®</sup>

THE NEW STANDARD OF QUALITY.

333 Welton Street  
P.O. Box 6308  
Hamden, CT 06517

(P): (800) 243-6256  
(F): (203) 248-8489  
(W): [www.specrail.com](http://www.specrail.com)

